



RISK OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH - Only intended for installation in accordance with the United States of America National Electrical Code, ANSI/NFPA-70, Article 398 or the equivalent. No serviceable parts.

Failure to follow these instructions may result in fatal or serious injury.

- Apply appropriate personal protective equipment and follow safe electrical work practices.
- This equipment must only be installed and serviced by qualified electrical personnel.


- Do not use this device on ungrounded systems.
- Verify ground connection exists and is in working order.
- Always confirm power is off by using an appropriate measuring device before performing services.
- Verify no loose connection or exposed ungrounded contact.
- Replace all devices, doors, and covers before turning on power to this equipment.

Introduction

The Bourns® SPD Model 1202 Series is designed to provide surge suppression on 120 V_{AC} and 120/240 V_{AC} lines. The unit consists of three wires (120 V_{AC}) or four wires (120/240 V_{AC}). The Model 1202 Series is rated for both indoor and outdoor installations.

Installation

Figure 1





NOTE: Before work begins, verify that the SPD is the correct unit and type for the intended installation.

1. Turn off all power sources before installation.
2. Install in accordance with Article 285 of the United States of America National Electrical Code.
3. To minimize lead length, install the SPD as close as possible to the branch circuit breaker or the intended electrical connection.
4. Open the electrical panel door and/or remove the cover.
5. Remove the appropriate trade size 1/2 inch knockout or punch a 7/8 inch (22 mm) hole through the electrical panel, if required.
6. Remove the locknut from the threaded nipple of the SPD.
7. Carefully untwist and insert the wires through the electrical panel knockout or hole (see Figure 1).
8. Replace locknut to securely anchor the SPD to the electrical panel enclosure. Ensure that the barbed side of the locknut is in contact with the metal of the enclosure.
9. Keep wire length as short as possible with no sharp bends. Do not twist, loop or coil wires.
10. Verify that the electrical panel ground system is present and installed per national and local codes.
11. Connect the white (neutral) wire to the neutral bar.
12. Connect the black (hot) wire to the circuit breaker.
13. Install the electrical panel cover and close door.
14. Re-energize the equipment. Verify that the indicator lamp on the SPD illuminates.

1202 Series
Type 1 Surge Protective Device (SPD)
INSTALLATION INSTRUCTIONS

Installation (Continued)



Diagnostic Operation

LED OFF = Loss of surge protection; check circuit breakers and connections. Verify line voltage at the point of connection; if all connections are correct, replace unit.

LED ON = Normal Operation

BOURNS®

Asia-Pacific: Tel: +886-2 2562-4117 • Email: asiacus@bourns.com

Europe: Tel: +36 88 885 877 • Email: eurocus@bourns.com

Mexico: Tel: +52 614 478 0400 • Email: mexicus@bourns.com

The Americas: Tel: +1-951 781-5500 • Email: americus@bourns.com

www.bourns.com